

## LH-008 (07-Up GM Silverado / Sierra)

### Installation Instructions

1. Detach the O.E. bezel from the tailgate handle by carefully pulling or prying with a flat head screwdriver at the retaining clip locations shown in figure 1.
2. Locate the three bolts that attach the handle to the tailgate and remove the lower bolt. (Fig. 2)
3. Position the lock assembly inside the tailgate and attach using the supplied screw. Loosen the top two bolts if needed for adjustment. (Fig. 3)
4. Align the lock mechanism with the handle's latch arms and tighten the mounting screw. (Fig.3) **Note: Tailgate must be in the closed position for proper installation.**
5. Attach new bezel by lining up the mounting clips on the rear of the bezel with the tailgate and press firmly to snap bezel into place.

